GENERAC[®]

Residential Standby Generators

GUARDIAN® SERIES

Air-Cooled Gas Engine

9/11 kW

1 of 5

INCLUDES:

9/11 kW

- True Power™ Electrical Technology
- Two Line LCD Multilingual Digital Evolution™ Controller (English/Spanish/ French /Portuguese)
- Two Transfer Switch Options Available: 100 Amp 16 CircuitSwitch or 200 Amp Service Rated Switch. See Page 4 for Details.
- Electronic Governor
- System Status & Maintenance Interval LED Indicators
- Sound Attenuated Enclosure
- Flexible Fuel Line Connector
- Direct-To-Dirt Composite Pad
- Natural Gas or LP Gas Operation
- 5 Year Limited Warranty
- Capability to be installed within 18" (457 mm) of a building*

Standby Power Rating

Models G007029-0, G007030-0 (Aluminum - Bisque) - 9 kW 60 Hz Models G007032-0, G007033-0 (Aluminum - Bisque) - 11 kW 60 Hz Model G007031-0 (Aluminum - Bisque) 11 kW 60 Hz





Note: CUL certification only applies to unbundled units and units packaged with pre-wired switches. Units packaged with the Smart Switch are UL certified in the USA only.

*Only if located away from doors, windows and fresh air intakes, and unless otherwise directed by local codes.

FEATURES

- INNOVATIVE DESIGN & PROTOTYPE TESTING are key components of GENERAC'S success in "IMPROVING POWER BY DESIGN." But it doesn't stop there. Total commitment to component testing, reliability testing, environmental testing, destruction and life testing, plus testing to applicable CSA, NEMA, EGSA, and other standards, allows you to choose GENERAC POWER SYSTEMS with the confidence that these systems will provide superior performance.
- O TRUE POWER™ ELECTRICAL TECHNOLOGY: Superior harmonics and sine wave form produce less than 5% Total Harmonic Distortion for utility quality power. This allows confident operation of sensitive electronic equipment and micro-chip based appliances, such as variable speed HVAC systems.

O TEST CRITERIA:

- PROTOTYPE TESTED
- SYSTEM TORSIONAL TESTED
- NEMA MG1-22 EVALUATION
- MOTOR STARTING ABILITY

- SOLID-STATE, FREQUENCY COMPENSATED VOLTAGE REGULATION. This stateof-the-art power maximizing regulation system is standard on all Generac models. It provides optimized FAST RESPONSE to changing load conditions and MAXIMUM MOTOR STARTING CAPABILITY by electronically torque-matching the surge loads to the engine. Digital voltage regulation at ±1%.
- SINGLE SOURCE SERVICE RESPONSE from Generac's extensive dealer network provides parts and service know-how for the entire unit, from the engine to the smallest electronic component.
- GENERAC TRANSFER SWITCHES. Long life and reliability are synonymous with GENERAC POWER SYSTEMS. One reason for this confidence is that the GENERAC product line includes its own transfer systems and controls for total system compatibility.



features and benefits

2 of 5

9/11 kW

• Integral sediment trap

Engine	
•Generac (OHVI) design	Maximizes engine "breathing" for increased fuel efficiency. Plateau honed cylinder walls and plasma moly rings helps the engine run cooler, reducing oil consumption resulting in longer engine life.
"Spiny-lok" cast iron cylinder walls	Rigid construction and added durability provide long engine life.
• Electronic ignition/spark advance	These features combine to assure smooth, quick starting every time.
• Full pressure lubrication system	Pressurized lubrication to all vital bearings means better performance, less maintenance and longer engine life. Now featuring up to a 2 year/200 hour oil change interval.
 Low oil pressure shutdown system 	Shutdown protection prevents catastrophic engine damage due to low oil.
 High temperature shutdown 	Prevents damage due to overheating.
Generator	
Revolving field	Allows for smaller, light weight unit that operates 25% more efficiently than a revolving armature generator.
Skewed stator	Produces a smooth output waveform for compatibility with electronic equipment.
Displaced phase excitation	Maximizes motor starting capability.
Automatic voltage regulation	Regulates the output voltage to $\pm 1\%$ prevents damaging voltage spikes.
•UL 2200 listed	For your safety.
Transfer Switch	
• Fully automatic	Transfers your vital electrical loads to the energized source of power.
•NEMA 3R	Can be installed inside or oustide for maximum flexibility.
Remote mounting	Mounts near your existing distribution panel for simple, low-cost installation.
Evolution™ Controls	
Auto/Manual/Off illuminated buttons	Selects the operating mode and provides easy, at-a-glance status indication in any condition.
•Two-line LCD multilingual display	Provides homeowners easily visible logs of history, maintenance and events up to 50 occurrences.
Sealed, raised buttons	Smooth, weather-resistant user interface for programming and operations.
 Utility voltage sensing 	Constantly monitors utility voltage, setpoints 65% dropout, 80% pick-up, of standard voltage.
Generator voltage sensing	Constantly monitors generator voltage to ensure the cleanest power delivered to the home.
• Utility interrupt delay	Prevents nuisance start-ups of the engine, adjustable 2-1500 seconds from the factory default setting of 5 seconds by a qualified dealer.
•Engine warm-up	Ensures engine is ready to assume the load, setpoint approximately 5 seconds.
•Engine cool-down	Allows engine to cool prior to shutdown, setpoint approximately 1 minute.
Programmable exerciser	Operates engine to prevent oil seal drying and damage between power outages by running the generator for 12 minutes every other week. Also offers a selectable setting for weekly or monthly operation providing flexibility and lower fuel costs to the owner.
Smart battery charger	Delivers charge to the battery only when needed at varying rates depending on outdoor air temperature. Compatible with lead acid and AGM-style batteries.
Main line circuit breaker	Protects generator from overload.
Electronic governor	Maintains constant 60 Hz frequency.
Unit	
SAE weather protective enclosure	Sound attenuated enclosures ensure quiet operation and protection against mother nature, withstanding winds up to 150 mph. Hinged key locking roof panel for security. Lift-out front for easy access to all routine maintenance items. Electro- statically applied textured epoxy paint for added durability.
 Enclosed critical grade muffler 	Quiet, critical grade muffler is mounted inside the unit to prevent injuries.
 Small, compact, attractive 	Makes for an easy, eye appealing installation, as close as 18" away from a building.
Installation System	
•1 ft (305 mm) flexible fuel line connector	Absorbs any generator vibration when connected to rigid pipe.
• Direct-to-dirt composite pad	Complex lattice design prevents settling or sinking of the generator system.
- Interrel and monthman	Description and a single production the first provide single production of the first sector of the M

Prevents particles and moisture from entering the fuel regulator and engine, prolonging engine life

GENERAC[®]

specifications

Model	G007029-0, G007030-0 (9 kW)	G007031-0, G007032-0, G007033-0 (11 k
	9.000 Watts*	11.000 Watts*
Rated Maximum Continuous Power Capacity (LP)	,	,
Rated Maximum Continuous Power Capacity (NG)	8,000 Watts* 240	10,000 Watts* 240
Rated Voltage Rated Maximum Continuous Load Current – 240 Volts (LP/NG)	37.5/33.3	
		45.8/41.7
Total Harmonic Distortion	Less than 5%	Less than 5%
Main Line Circuit Breaker	40 Amp	50 Amp
Phase	1	1
Number of Rotor Poles	2	2
Rated AC Frequency	60 Hz	60 Hz
Power Factor	1.0	1.0
Battery Requirement (not included)		num or Group 35AGM 650 CCA Minimum
Unit Weight (lb/kg)	340/154	348/158
Dimensions (L x W x H) in/mm		/1218 x 638 x 732
Sound output in dB(A) at 23 ft (7 m) with generator operating at normal load**	66	63
ingine		
Type of Engine	GENERAC OHVI	GENERAC OHVI V-TWIN
Number of Cylinders	1	2
Displacement	426 cc	530 cc
Cylinder Block	Aluminum w/ Cast Iron Sleeve	Aluminum w/ Cast Iron Sleeve
Valve Arrangement	Overhead Valve	Overhead Valve
Ianition System	Solid-state w/ Magneto	Solid-state w/ Magneto
Governor System	Electronic	Electronic
Compression Ratio	9.0:1	9.5:1
Starter	12 Vdc	12 Vdc
Oil Capacity Including Filter	Approx. 1.1 gt/1.0 L	Approx. 1.7 qt/1.6 L
Operating rpm	3.600	3,600
Fuel Consumption	0,000	0,000
Natural Gas ft ³ /hr (m ³ /hr)		
1/2 Load	109 (3.09)	123 (3.48)
Full Load	133 (3.77)	199 (5.64)
)	
Liquid Propane ft ³ /hr (gal/hr) [l/hr]		
Liquid Propane ft ³ /hr (gal/hr) [l/hr] 1/2 Load	36 (1.00) [3.79]	43 (1.19) [4.49]
1/2 Load Full Load	54 (1.50) [5.66]	73 (2.01) [7.62]
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22)
1/2 Load Full Load	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 i
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22)
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft³/hr x 2500 (LP) or ft³/hr x 1000 (NG). For Controls	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 //hr x 37.26 (NG).
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft³/hr x 2500 (LP) or ft³/hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 //hr x 37.26 (NG). e for ease of operation.
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 //hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser.
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interfac Automatic Start on Utility fai Start with starter control, unit stays on.	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 //hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place.
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft*/hr x 2500 (LP) or ft*/hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interfac Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed.	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate.
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft%/hr x 2500 (LP) or ft%/hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft%/hr x 2500 (LP) or ft%/hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interfac Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 //hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft%/hr x 2500 (LP) or ft%/hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 //hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only)
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting)	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only) '1 V/190-216 V
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft%/hr x 2500 (LP) or ft%/hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only) '1 V/190-216 V ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only) '1 V/190-216 V ndard ents Each
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft%/hr x 2500 (LP) or ft%/hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only) '1 V/190-216 V ndard ents Each five times at factory set intervals and durations.
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft%/hr x 2500 (LP) or ft%/hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only) '1 V/190-216 V ndard ents Each five times at factory set intervals and durations. 5 sec. after engine has stopped.
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 //hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only) '1 V/190-216 V ndard ents Each 'five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 //hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only) '1 V/190-216 V ndard ents Each 'five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft³/hr x 2500 (LP) or ft³/hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 //hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only) '1 V/190-216 V ndard ents Each 'five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard ndard ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication Automatic Voltage Regulation with Over and Under Voltage Protection	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 //hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only) '1 V/190-216 V ndard ents Each 'five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication Automatic Voltage Regulation with Over and Under Voltage Protection	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta Sta Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 //hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only) '1 V/190-216 V ndard ents Each 'five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard ndard ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication Automatic Voltage Regulation with Over and Under Voltage Protection Under-Frequency/Overload/Stepper Overcurrent Protection Starter Lock-out	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta Sta Sta Sta Sta Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 //hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard mable by dealer only) '1 V/190-216 V ndard ents Each 'five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard ndard ndard ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication Automatic Voltage Regulation with Over and Under Voltage Protection Under-Frequency/Overload/Stepper Overcurrent Protection	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta Sta Sta Sta Sta Sta Sta Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only) '1 V/190-216 V ndard ents Each 'five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard ndard ndard ndard ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication Automatic Voltage Regulation with Over and Under Voltage Protection Under-Frequency/Overload/Stepper Overcurrent Protection Safety Fused/Fuse Problem Protection Automatic Low Oil Pressure/High Oil Temperature Shutdown	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta Sta Sta Sta Sta Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only) '1 V/190-216 V ndard ents Each 'five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard ndard ndard ndard ndard ndard ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication Automatic Voltage Regulation with Over and Under Voltage Protection Under-Frequency/Overload/Stepper Overcurrent Protection Safety Fused/Fuse Problem Protection Automatic Low Oil Pressure/High Oil Temperature Shutdown Overcrank/Overspeed (@ 72 Hz)/rpm Sense Loss Shutdown	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta Sta Sta Sta Sta Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. illure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard mable by dealer only) '1 V/190-216 V ndard mits Each five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication Automatic Voltage Regulation with Over and Under Voltage Protection Under-Frequency/Overload/Stepper Overcurrent Protection Safety Fused/Fuse Problem Protection Automatic Low Oil Pressure/High Oil Temperature Shutdown Overcrank/Overspeed (@ 72 Hz)/rpm Sense Loss Shutdown	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta Sta Sta Sta Sta Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 / /hr x 37.26 (NG). e for ease of operation. illure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard mable by dealer only) 11 V/190-216 V ndard mits Each five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication Automatic Voltage Regulation with Over and Under Voltage Protection Under-Frequency/Overload/Stepper Overcurrent Protection Safety Fuse/Fuse Problem Protection Automatic Low Oil Pressure/High Oil Temperature Shutdown Overcrank/Overspeed (@ 72 Hz)/rpm Sense Loss Shutdown High Engine Temperature Shutdown	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta Sta Sta Sta Sta Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. illure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard mable by dealer only) '1 V/190-216 V ndard mate Each five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft³/hr x 2500 (LP) or ft³/hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 //hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only) '1 V/190-216 V ndard ents Each 'five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard ndard ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication Automatic Voltage Regulation with Over and Under Voltage Protection Under-Frequency/Overload/Stepper Overcurrent Protection Safety Fused/Fuse Problem Protection	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta Sta Sta Sta Sta Sta Sta Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 i //hr x 37.26 (NG). e for ease of operation. ilure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard ndard mable by dealer only) '1 V/190-216 V ndard ents Each 'five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard ndard ndard ndard ndard ndard ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication Automatic Voltage Regulation with Over and Under Voltage Protection Under-Frequency/Overload/Stepper Overcurrent Protection Safety Fused/Fuse Problem Protection Automatic Low Oil Pressure/High Oil Temperature Shutdown	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta Sta Sta Sta Sta Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. illure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard mable by dealer only) 11 V/190-216 V ndard mits Each five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication Automatic Voltage Regulation with Over and Under Voltage Protection Under-Frequency/Overload/Stepper Overcurrent Protection Safety Fused/Fuse Problem Protection Automatic Low Oil Pressure/High Oil Temperature Shutdown Overcrank/Overspeed (@ 72 Hz)/rpm Sense Loss Shutdown	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta Sta Sta Sta Sta Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. illure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard mable by dealer only) '1 V/190-216 V ndard mits Each five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication Automatic Voltage Regulation with Over and Under Voltage Protection Under-Frequency/Overload/Stepper Overcurrent Protection Safety Fused/Fuse Problem Protection Automatic Low Oil Pressure/High Oil Temperature Shutdown Overcrank/Overspeed (@ 72 Hz)/rpm Sense Loss Shutdown	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta Sta Sta Sta Sta Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. illure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard mable by dealer only) '1 V/190-216 V ndard ents Each 'five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication Automatic Voltage Regulation with Over and Under Voltage Protection Under-Frequency/Overload/Stepper Overcurrent Protection Safety Fused/Fuse Problem Protection Automatic Low Oil Pressure/High Oil Temperature Shutdown Overcrank/Overspeed (@ 72 Hz)/rpm Sense Loss Shutdown Internal Fault/Incorrect Wiring Protection	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta Sta Sta Sta Sta Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. illure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard mable by dealer only) '1 V/190-216 V ndard mate Each five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard
1/2 Load Full Load Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel in mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500 (LP) or ft ³ /hr x 1000 (NG). For Controls 2-Line Plain Text Multilingual LCD Display Mode Buttons: Auto Manual Off Ready to Run/Maintenance Messages Engine Run Hours Indication Programmable start delay between 2-1500 seconds Utility Voltage Loss/Return to Utility Adjustable (Brownout Setting) Future Set Capable Exerciser/Exercise Set Error Warning Run/Alarm/Maintenance Logs Engine Start Sequence Starter Lock-out Smart Battery Charger Charger Fault/Missing AC Warning Low Battery/Battery Problem Protection and Battery Condition Indication Automatic Voltage Regulation with Over and Under Voltage Protection Under-Frequency/Overload/Stepper Overcurrent Protection Safety Fused/Fuse Problem Protection Automatic Low Oil Pressure/High Oil Temperature Shutdown Overcrank/Overspeed (@ 72 Hz)/rpm Sense Loss Shutdown	54 (1.50) [5.66] let at all load ranges - 3.5-7" water column (7-13 mm r Megajoule content, multiply m³/hr x 93.15 (LP) or m³ Simple user interface Automatic Start on Utility fai Start with starter control, unit stays on. Stops unit. Power is removed. Sta Standard (program From 140-17 Sta Standard (program From 140-17 Sta 50 Eve Cyclic cranking: Engine cranks a maximum of Starter cannot re-engage until Sta Sta Sta Sta Sta Sta Sta Sta	73 (2.01) [7.62] mercury) for natural gas, 10-12" water column (19-22 /hr x 37.26 (NG). e for ease of operation. illure. Programmable exerciser. If utility fails, transfer to load takes place. Control and charger still operate. ndard mable by dealer only) '1 V/190-216 V ndard ents Each 'five times at factory set intervals and durations. 5 sec. after engine has stopped. ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard ndard

9/11 kW

*Sound levels are taken from the front of the generator. Sound levels taken from other sides of the generator may be higher depending on installation parameters. Rating definitions - Standby: Applicable for supplying emergency power for the duration of the utility power outage. No overload capability is available for this rating. (All ratings in accordance with BS5514, ISO3046 and DIN6271). * Maximum wattage and current are subject to and limited by such factors as fuel Btu/megajoule content, ambient temperature, altitude, engine power and condition, etc. Maximum power decreases about 3.5 percent for each 1,000 feet (304.8 meters) above sea level; and also will decrease about 1 percent for each 6 °C (10 °F) above 16 °C (60 °F).

GENERAC

switch options

9/11 kW

Limited Circuits Switch Features

- 16 circuits.
- Electrically operated, mechanically-held contacts for fast, positive connections.
- Rated for all classes of load, 100% equipment rated, both inductive and resistive.
- 2 pole, 250 VAC contactors.
- 30 millisecond transfer time.
- Single coil design.
- Main contacts are silver plated or silver alloy to resist welding and sticking.
- NEMA/UL 3R aluminum outdoor enclosure.
- Multi listed for use with 1" standard, tandem, GFCI and AFCI breakers from Siemens, Murray, Eaton and Square D for the most flexible and cost effective install.

Model	G007030-0 (9 kW)	G007032-0 (11 kW)
No. of Poles	2	2
Current Rating (Amps)	100	100
Voltage Rating (VAC)	250	250
Utility Voltage Monitor (Fixed)*		
-Pick-up	80%	80%
-Dropout	65%	65%
Return to Utility*	approx. 15 sec	approx. 15 sec
Exerciser bi-weekly for 12 minutes*†	Standard	Standard
UL Listed	Standard	Standard
Total of Pre-wired Circuits	16	16
No. 15 A 120 V	5	5
No. 20 A 120 V	5	5
No. 20 A 240 V	1	1
No. 30 A 240 V	-	-
No. 40 A 240 V	1	1
No. 50 A 240 V	1	1
Tandem Breaker Capabilities	8 Tandems	8 Tandems
Circuit Breaker Protected Available RMS Symmetrical		
Fault Current @ 250 Volts	10,000	10,000

*Function of Evolution Controller † Can be set to weekly or monthly

Dimensions

	200 Amps 120/240, 1ø				
		Open Transition Service Rated			
	Height		Width		Depth
	H1	H2	W1	W2	Deptil
in	27.24	30.0	11.4	13.5	7.09
mm	692.0	762.4	289.0	343.0	180.0

Note: The 50 amp switch is flush mountable. H1 and W1 refer to mounting hole spacing. H2 and W2 are cover dimensions. H3 and W3 are the enclosure dimensions without cover.

Wire Ranges		
Conductor Lug	Neutral Lug	Ground Lug
1/0 - #14	2/0 - #14	2/0 - #14

Service Rated Smart Switch Features available on 11 kW model only

- Includes Digital Power Management Technology standard (DPM).
- Intelligently manages up to four air conditioner loads with no additional hardware.
- Up to eight more large (240 VAC) loads can be managed when used in conjunction with Smart Management Modules (SMMs).
- · Electrically operated, mechanically-held contacts for fast, clean connections.
- Rated for all classes of load, 100% equipment rated, both inductive and resistive.
- Service equipment rated, dual coil design.
- Rated for both aluminum and copper conductors.
- · Main contacts are silver plated or silver alloy to resist welding and sticking.
- NEMA/UL 3R aluminum outdoor enclosure.

Dimensions

	200 Amps 120/240, 1ø Open Transition Service Rated				
	Hei	ght	Wi	dth	Depth
	H1	H2	W1	W2	Deptil
in	27.24	30.0	11.4	13.5	7.09
mm	692.0	762.4	289.0	343.0	180.0



Model	G007033-0 (11 kW)
No. of Poles	2
Current Rating (Amps)	200
Voltage Rating (VAC)	250
Utility Voltage Monitor (Fixed)*	
-Pick-up	80%
-Dropout	65%
Return to Utility*	approx. 13 sec.
Exercise weekly for 12 minutes*	Standard
UL Listed	Standard
Enclosure Type	NEMA/UL 3R
Withstand Rating (Amps)	22,000
Lug Range	250 MCM - #6

*Function of Evolution Controller



4 of 5

GENERAC

9/11 kW

available accessories

	<u> </u>

Model #	Product	Description
G006463-3	Mobile Link™	Generac's Mobile Link allows you to check the status of your generator from anywhere that you have access to an Internet connection from a PC or with any smart device. You will even be notified via e-mail or text message when a change in the generator's status occurs. Available in the U.S. only.
G005819-0	26R Wet Cell Battery	Every standby generator requires a battery to start the system. Generac offers the recommended 26R wet cell battery for use with all air-cooled standby product excluding PowerPact®.
G007101-0	Battery Pad Warmer	The pad warmer rests under the battery and will warm the battery. Recommended for use if the temperature regularly falls below 0° F. (Not necessary for use with AGM-style batteries)
G007102-0	Oil Warmer	Oil warmer slips directly over the oil filter. Recommended for use if the temperature regularly falls below 0° F.
G007103-0	Breather Warmer	The breather warmer is for use in extreme cold weather applications. For use with Evolution controllers only in climates where heavy icing occurs.
G005621-0	Auxiliary Transfer Switch Contact Kit	The auxiliary transfer switch contact kit allows the transfer switch to lock out a single large electrical load you may not need. Not compatible with 50 amp pre-wired switches.
G007027-0	Fascia Base Wrap Kit	The fascia base wrap snaps together around the bottom of the new air cooled generators. This offers a sleek, contoured appearance as well as offering protection from rodents and insects by covering the lifting holes located in the base.
G005703-0	Paint Kit	If the generator enclosure is scratched or damaged, it is important to touch-up the paint to protect from future corrosion. The paint kit includes the necessary paint to properly maintain or touch-up a generator enclosure.
G006482-0 - 9 kW G006483-0 - 11 kW	Scheduled Maintenance Kit	Generac's scheduled maintenance kits provide all the hardware necessary to perform complete routine maintenance on a Generac automatic standby generator.
G006664-0	Wireless Remote Monitor	Completely wireless and battery powered, Generac's wireless remote monitor provides you with instant status information without ever leaving the house. Not compatible with CorePower or EcoGen systems.
G006873-0	Smart Management Module (50 Amps)	Smart Management Modules are used in conjunction with the Automatic Transfer Switch to increase its power management capabilities. It provides additional power management flexibility not found in any other power management system.

dimensions & UPCs

Dimensions shown are approximate. Refer to installation manual for exact dimensions. DO NOT USE THESE DIMENSIONS FOR INSTALLATION PURPOSES.





Model	UPC
G007029-0	696471070293
G007030-0	696471070309
G007031-0	696471070316
G007032-0	696471070323
G007033-0	696471070330